TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Model: 3RAWZ481ETH0
(Graphite)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: 3RAWZ481ETH0
(Graphite)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8545902	Label, Wiring Diagram
	W10127718	Use & Care Guide
	8563878	Installation Instructions
	W10131548	Installation & User Guide
2	8519253	Top
3	W10110980	Harness, Main
4	W10118949	Panel, Console (Includes Illus. 13, 14 15, 17, 18 & 19)
5	3394427	Clip, Harness
6	W10118067	Bracket, Console
7	353424	Connector, Sensor
8	94614	Terminal
9	3936144	Plug, Terminal
10	94613	Terminal
11	W10080700	Screw, 8−18 x 1/2
12	488886	Screw, 8−18 x 1/2
13	W10129617	Button, Push−To−Start
14	W10118063	Bracket, Timer
15	W10118064	Bracket, Switch Mounting
16	W10080930	Screw, 8−18 x 1/2
17	W10117943	Medallion
18	W10129618	Console, Center
19	3400238	Screw, 2−28 x 1/2
20	W10116280	Timer
21	W10111181	Fuse
22	W10080820	Screw, 8−18 x 5/16
23	3980421	Spacer Plate (Timer)
24	8316076	Switch, Wrinkle Guard
25	8522378	Buzzer, Mini
26	W10112668	Switch, Push−To−Start
27	3399642	Switch, Temperature
28	W10110978	Harness, Console
29	3347243	Connector, 6−Circuit
30	3397269	Connector, Timer
31	3401144	Connector (PTS Relay)
32	692997	Connector
33	W10129615	Knob, Timer Assembly
34	W10129614	Knob, Control (2)
35	3980339	Shield, Drip
36	688805	Spring, Clip

CABINET PARTS

For Model: 3RAWZ481ETH0
(Graphite)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: 3RAWZ481ETH0
(Graphite)

Illus. No.	Part No.	DESCRIPTION
1	W10119283	Cover, Terminal Block
2	W10130935	Screw, 8−32 x 5/16
3	W10080550	Screw, 10−32 x 5/8 (Ground)
4	3397659	Block, Terminal
5	8318457	Switch, Broken Belt
6	8521947	Dry Rack (Top)
7	8578439	Panel, Side (L.H.)
8	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	W10080670	Retainer, Idler
12	3979261	Plug, Multivent
13	3388672	Pulley Assembly
14	279318	Terminal, Brass & Tinned (3) (Includes Illus. 33)
15	W10083220	Lever, Snap Switch
16	3394081	Wire, Belt Switch
17	W10128772	Sound Panel
18	233520	Washer, Thrust
19	8543119	Wire, Jumper (Includes Illus. #41)
20	W10121334	Tri Ring
21	8066115	Cover−Plate
22	8529053	Ramp, Door
23	8521961	Dry Rack Support
24	8578452	Panel, Side (R.H.)
25	8521950	Dry Rack Assembly
26	3393657	Restrainer, Belt
27	3404470	Motor, Assembly 50 HZ.
28	3400097	Screw, 10−24 x 3/8
29	3402548	Pulley 50 HZ.
30	3387610	Belt, Drive
31	8541503	Kit, Stack Assembly
32	3387118	Bracket, Motor
33	279393	Terminal Block Screw Kit (For Terminal Block)
34	49026	4" − 90° Elbow
35	8316644	Clip, Strain Relief
36	8563747	Exhaust Pipe & Bracket
37	8563750	Exhaust Pipe (Short)
38	8563749	Exhaust Pipe (Long)
39	W10118754	Idler Bracket
40	692400	Nut, Push−In
41	8541808	Switch, Door
42	W10118188	Screw, 6−20 x 1 1/16
43	W10080700	Screw, 8−18 x 1/2
44	3387242	Seal, Front Panel
45	W10080710	Screw, 10−16 x 1/2
46	8519459	Clip, Toe Panel
47	340025	Wire, Ground
48	W10118075	Panel−Rear
49	W10116275	Toe, Panel
50	W10119292	Base, Cabinet
51	8562164	Front Panel
52	W10080240	Strike, Door (2)
53	W10080280	Screw, 8−18 x 3/8
54	W10119274	Bracket, Control
55	62825	Clip, S Type (3)

Optional Parts Not Included

Dryer Exhaust Kit (For Side & Bottom Venting)

66	279969	Grey

BULKHEAD PARTS

For Model: 3RAWZ481ETH0
(Graphite)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: 3RAWZ481ETH0
(Graphite)

Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread
2	W10080700	Screw, 8−18 x 1/2
3	3394984	Door, Lint Screen
4	W10130935	Screw, 8−32 x 5/16
5	697354	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front
8	W10080210	Nut,3/8 x 16(R.H.)
10	696302	Shield, Exhaust
11	W10080820	Screw, 8−18 x 5/16
12	8572105	Clip, Exhaust Pipe
13	3390291	Thermostat 250°F (121°C)
14	3387749	Heater Element
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
16	W10080190	Nut, 3/8−16 (L.H.)
17	3387809	Bulkhead, Rear
18	W10080960	Washer, Support
19	8575325	Shaft, L.H. Thread
20	690997	Ring, Tri
21	8536973	Roller, Support
22	W10119260	Exhaust Pipe
23	3394985	Housing, Outlet
24	8529007	Plug, Rear Bulkhead
25	W10117531	Complete Drum Assembly
26	W10109200	Screw, 11−16 x 3/4
27	697694	Seal, Drum
28	W10080400	Screw, 8−18 x 1/2
29	W10080280	Screw, 8−18 x 3/8
30	W10118335	Channel Bracket, Rear Bulkhead (2)
31	W10118337	Bracket, Upper Rear Bulkhead
32	W10080380	Screw, 8−18 x 5/8
33	8066099	Bracket, Heater Box
34	W10080590	Screw, 10−16 x 1/2
35	W10080640	Screw, 10−16 x 1
36	W10113136	Baffle−Drum
37	697772	Wheel, Blower
38	8519245	Bulkhead, Front
39	3394986	Spring, Lint
40	8299979	Grill, Outlet Screen Door
41	697770	Seal, Cover Plate
42	3387137	Thermistor
43	W10049370	Lint−Screen
44	W10119255	Housing, Blower
45	8066168	Lint Duct Assembly
46	3392537	Heater Box
47	3977394	Thermal Cut−Off (Includes Illus. 13)

DOOR PARTS

For Model: 3RAWZ481ETH0
(Graphite)



Illus. No.	Part No.	DESCRIPTION
1	W10085230	Label−Hinge Hole
2	W10111142	Door Hinge Assembly
3	8519483	Cover, Door Hinge
4	W10080840	Screw, 8−18 x 5/8
6	690081	Door Catch Assembly (Bottom)

Illus. No.	Part No.	DESCRIPTION
7	8559751	Handle, Door
8	W10017850	Screw, 10−24 X 3/64
9	8519374	Plug, Door Handle (2)
10	W10118207	Door Assembly (Inner) (Includes Illus. 6 & 14)

Illus. No.	Part No.	DESCRIPTION
11	W10080340	Screw, 8−18 x 11/16
12	8519327	Door, Outer
13	8545878	Window
14	3389441	Door Catch AssemblY (Top)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: 3RAWZ481ETH0
(Graphite)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	4396174	Pewter
		PAINT, PRESSURIZED SPRAY (12 oz.)
	4396175	Pewter
	350938	Primer, Gray
		ACCESSORY PARTS
	8529894	Hold Down Kit